



Important information

After (seasonal) use, make sure the Fairybell® is completely dry. Lay the Fairybell® out on the ground and tie the orange ribbons around various sections of the Fairybell® (straps with lights) so that next season you start with an untangled Fairybell®.

When placing the Fairybell® back into the box, hold the top hook and lower the bottom part (plugs and elastics) first into the box and finish on top with the hook.

Always store the Fairybell® in a clean and dry place.

Lower the Fairybell® at windforce 6 or higher.

Missing parts or defects

All spare parts can be ordered at our webshop.

See 'service request' at our webshop.

Need help?

Do you need help with placing the Fairybell®?

Scan the QR code below to watch the instructional videos from our products.

Scan QR for our
instructional videos



www.fairybell.com

**Fairybell® is a registered trademark of
Hemsson Holding BV www.fairybell.com**

This is a worldwide patented product | Certifications: CE and
RoHS compliant | FSP0923



Fairybell® Luminous Switch



Multicolour



Rotate the plug



Warm White

Assembly instructions - Opbouw instructies
Aufbauanleitung - Instruction de construction
Istruzioni di assemblaggio - Monteringsanvisning

